

Quick Start Guide Media Technology Type D2

Switch on media technology

Touch the touchpanel and tap „Medientechnik Einschalten“.

Medientechnik einschalten

Lecture hall PC

Switch on the desk computer and smart podium.

Mouse and keyboard are located under the lectern.

Login:

Username: gwdg\username

OR: ug-student\name.firstname

Password: *****

Notebook (optional)

Connect to the available ports (HDMI & VGA).

If you want to play sound, please use HDMI cable or plug in the audio cable with VGA.

Projection selection

notebook on beamer incl. audio, handheld microphone and headset

Notebook auf Beamer inkl. Audio schalten, Handsendemikro und Headset

Lecture hall pc to beamer incl. audio, handheld microphone and headset

Hörsaal PC auf Beamer inkl. Audio schalten, Handsendemikro und Headset

Desk microphone, handheld microphone and headset, beamer switched off

Pultmikro, Handsender und Headset einschalten; Beamer wird ausgeschaltet


notebook to beamer incl. audio. microphone switched on, camera with preset lectern on preview monitor

Notebook auf Beamer inkl. Audio schalten; Mikrofonie einschalten; Kamera mit Preset Pult auf Vorschaumonitor

By selecting a scenario, all necessary basic settings are made: The projector is switched on and the correct source is selected, the microphones are activated. When **playing audio** and video files, please make sure that you have selected the correct audio source (PC/notebook) under "Audio" to be able to play the sound in the lecture hall.

Turn on microphones


Note: If the microphones do not work, check the mute function



Document camera (optional)

Switch on the document camera if necessary!

If you use **transparent slides**, please switch on the backlight on the left side of the device.



Press 3 seconds to turn off

Switch off media technology!

To do this, press the „**Ende**“ button on the touchpanel to switch of the beamer bevor you leave the room.

Please do not change anything in the wiring!

Please report malfunctions to the telephone number 0551 39-**1171**!

Janitor: 24480

For detailed instructions and additional information scan QR code

